



**Presto Stantest Pvt. Ltd.**

I-42, DLF Industrial Area Phase-1, Delhi Mathura Road, Faridabad 121003, Haryana, India

P : 9210 903 903, +91 129 4272727, 93111 24302 E : info@prestogroup.com

• Faridabad • Sonapat • Kolkata • Mumbai • Pune • Ahmedabad  
• Chennai • Bangalore • Hyderabad

[www.prestogroup.com](http://www.prestogroup.com)



## SECURE SEAL TESTER FOR BOTTLES



Secure Seal Tester – Next Generation Model is a consistent tool useful to measure the thread and seal integrity on bottles either Pet or Glass. The bottle secure seal tester has been designed to address the special needs of sealing beverage containers that use various seals, such as aluminum roll-on, twist crowns. By detecting gas leakage rather than liquid, the Secure Seal Tester gives more sensitive, accurate readings.

- HMI based Touchscreen Model
- Automatic sample testing through easy pressure release mechanism
- Pneumatic sample covering and movement for Bottle Fitting and testing
- Pneumatic penetration of piercing fixture on bottle caps
- Pressure, Inlet Pressure setting and Preset Timer functions incorporated in HMI for accuracy and repeatability
- Program profile for selecting test parameters and performing the test.
- Easy Data Management. User can create product identification, test pressure, time etc.
- USB option available for storing test data
- Data output in excel format.
- Current test running status display
- Changeable Pressure Units
- Inbuilt Calibration facility
- 2 layer safety container
- Emergency press

### Software Feature:

- Touch screens comply with IP65 / NEMA4 standards CE & UL approved
- 7" TFT LCD 65536 colours
- ARM9 32-bit CPU; Function keys
- 640 x 480 pixels
- 8M Flash Memory
- 512K bytes
- SRAM Supports SM card

[www.prestogroup.com](http://www.prestogroup.com)





## Presto Stantest Pvt. Ltd.

I-42, DLF Industrial Area Phase-1, Delhi Mathura Road, Faridabad 121003, Haryana, India

P : 9210 903 903, +91 129 4272727, 93111 24302 E : info@prestogroup.com

• Faridabad • Sonapat • Kolkata • Mumbai • Pune • Ahmedabad  
• Chennai • Bangalore • Hyderabad

[www.prestogroup.com](http://www.prestogroup.com)



### Key Specifications:

Display	HMI Based touchscreen
Equipment Range	220 psi
Test Range	175 psi
Accuracy	±2% at full range
Least Count/Resolution	0.1 psi
Power	220V , Single phase, 50 Hz
Pressure Unit	Inbuilt in HMI (changeable in Kg/cm <sup>2</sup> psi& bar
Inner Size of testing container	L 250 x W 225 X H 450 mm
Timer	Inbuilt in HMI Preset upto 999 seconds
Pressure Release	Auto pressure release system
Sample Holder	Piercing fixture for cap

### Highlights:

Material	Test container poly carbonated sheet
Finish	Powder coated Havel Gray & Blue combination finish and bright chrome / zinc plating for corrosion resistant finish
Dimensions	705x570x700mm

- High pressure regulated airline not in our scope of supply

### Optional Features:

- Piercing tool extra on chargeable

### OUR OTHER PRODUCTS :-

					
Box Compression Tester	Scuff Resistance Tester	Tensile Tester Digital	Spectrocolorimeter	Cobb Sizing Tester	Digital GSM Balance

[www.prestogroup.com](http://www.prestogroup.com)

