



Presto Stantest Pvt. Ltd.

I-42, DLF Industrial Area Phase-1, Delhi Mathura Road, Faridabad 121003, Haryana, India
P : 9210 903 903, +91 129 4272727, 93111 24302 E : info@prestogroup.com

• Faridabad • Sonapat • Kolkata • Mumbai • Pune • Ahmedabad
• Chennai • Bangalore • Hyderabad

www.prestogroup.com



Profile Projector - Digital with DRO



Model No. PPPD 0116 (DRO)

Cost effective solution for Digital linear & angular Measurements with built-in DRO

Standard Features :

Compact light weight Table Top model with easy operations. 300mm diameter screen with 90° cross line and chart holders. Screen is graduated to 360° with vernier reading 1 minutes. Projection Light Source with 24V / 150W Halogen Lamp. Double Oblique Light Source for Surface Illumination. Two adjustable dichromic reflector lamps 12V/100W each. Focusing can be adjusted manually by hand wheel. High Quality objective lenses. Optical distortion below 0.15%. Standard magnifications : 10x,

Optional :

20x, 50x and 100x Measurements available.





Presto Stantest Pvt. Ltd.

I-42, DLF Industrial Area Phase-1, Delhi Mathura Road, Faridabad 121003, Haryana, India

P : 9210 903 903, +91 129 4272727, 93111 24302 E : info@prestogroup.com

• Faridabad • Sonapat • Kolkata • Mumbai • Pune • Ahmedabad
• Chennai • Bangalore • Hyderabad

www.prestogroup.com



Key Specifications:

Table type & size	AL 300 x 200 mm
Effective table area	275 x 180 mm
X-Y range	200 x 100 mm
Measuring unit	Built in linear scales
Resolution	0.001 mm
Screen Size	300 mm
View Field Diameter	30 mm
Working distance	65 mm

Highlights:

X - Y Counter	Yes
Digital angle counter	Yes
Maximum work piece height	115 mm

Optional :

- 20x, 50 x and 100x measurements available.
- Rotary measuring stage
- Sample Holding Fixture

Thank you customers for choosing us as your partners in growth !



*All the above logos are the sole property of their respective owners and are used purely for depiction purposes only.

OUR OTHER PRODUCTS :-

Top Load Tester	Wall Thickness Gauge	Gloss Meter Triangle	Eccentricity Tester	Moisture Analyzer MB 45	Preform Neck Cutter

